

GoPro Hero 5: Black

Waterproof up to 30 feet

Record Button



Mini HDMI/
USB-C
compartment



Speaker

Battery/Mini
SD card
compartment

Power/Mode Button
Selects
photo/video/rapid
shots/timelapse

Settings can also be
viewed or changed
on touch screen



Shooting Mode

Time
recorded/Shots
taken

Space Left

Battery



powered by

 **PIKTOCHART**